

## **Residential LCD Functions Sheet**

**To arm system GREEN READY LIGHT must be on!**

If green light is not on press < > to find out what zone is open

**ARMING AWAY- green ready must be on – enter your four-digit code (1234)** or press and hold the away button for five seconds and wait for red-armed light and audible count down to come on.

**STAY ARMING- green ready must be on – enter your four-digit code (1234)** and stay in the house or hold the stay button for five seconds and wait for the red-armed light to come on. **NOTE:** There is no audible count down when stay button is used.

**DISARMING- enter your four-digit code (1234)** - Turns off protection.

**BYPASS - For example (\* + 1 + use < > to find the zone you want to bypass + \* + # + your code) this bypasses the zone and arms the system.** This temporarily removes a protected zone from the system. Once the system has been disarmed the bypass will be removed.

**ACCIDENTAL ALARM - WHAT TO DO: Enter your four-digit code.** This will turn the siren off and sends a cancellation signal to the monitoring station. After disarming system, please **call Huronia Alarm and Fire Security Inc.** and provide your ID Number.

If you make a mistake entering in your four digit-code pres the # and begin again.

Our monitoring station phone numbers are;

**705 527 9311 or 1 888 363 9311**

