

Residential Fixed LCD Functions Sheet

To arm system GREEN READY LIGHT must be on!

If there is no green light and the keypad says open press the # and look at the LCD number to find out what zone is open

ARMING AWAY- green ready must be on – enter your four-digit code (1234) or press and hold the away button for five seconds and wait for red armed light and audible count down to come on.

STAY ARMING- green ready must be on – enter your four-digit code (1234) and stay in the house or hold the stay button for five seconds and wait for red armed light to come on. **NOTE:** There is no audible count down when stay button is used.

DISARMING- enter your four-digit code (1234) - Turns off protection.

BYPASS - For example (* + 1 + the zone 06 + # + your code) this bypasses zone 6 and arms the system with a bypass - This temporarily removes a protected zone from the system. Once the system has been disarmed the bypass will be removed.

ACCIDENTAL ALARM - WHAT TO DO: Enter your four-digit code. This will turn the siren off and sends a cancellation signal to the monitoring station. After disarming system, please **call Huronia Alarm and Fire Security Inc.** and provide your ID Number.

If you make a mistake entering in your four digit-code pres the # and begin again.

Our monitoring station phone numbers are;

705 527 9311 or 1 888 363 9311

